



SR20 Crank/Cam 60-2 Sensor Kit

Parts

Mazworx/ATI Damper Outer Shell with 60-2 Teeth (Comes either as a shell or complete damper)
Cam Angle Sensor Wheel with 1 Magnet (installed) and Hardware
Magnetic Pickup Sensor with Bracket and Hardware
Hall Pickup Sensor with Bracket and Hardware
SR FWD Distributor Block-Off

Instructions

1. Remove the 16mm freeze plug in front of the exhaust cam gear and install the cam sensor bracket and the **Hall Effect** sensor.



2. Install the Cam Angle Sensor Wheel on exhaust cam. You will have to change the dowel pin on the cam to the longer one. Use longer bolt supplied to mount wheel and cam gear to cam.



3. Grind inside of the valve cover to clear Cam Angle Sensor Wheel as shown. Verify clearance.



4. Install pulley, crank sensor bracket and the **Magnetic Sensor**.



5. Install block off where the FWD distributor used to go.



6. Consult with your tuner for ECU settings.